

INSTRUCTION MANUAL



AR 2000 S (A)
AR 2000M (A)
AR 2000 H (A)

CONTENTS

INTRODUCTION.....	1
IMPORTANT SAFETY INSTRUCTIONS.....	2
NOMENCLATURE	5
TECHNICAL DATA	6
PREPARATION BEFORE USE ...	7
OPERATING THE AIR RIVETER...	8
MAINTENANCE	9
STORAGE	14
TROUBLESHOOTING	15
AR2000S(A) EXPLODED VIEW ...	17
AR2000M(A) EXPLODED VIEW...	19
AR2000H(A) EXPLODED VIEW...	21

Professional model of air riveter to install blind rivets.

- Thank you very much for purchasing "LOBSTER" air riveter. To ensure correct operation, please read this instruction manual carefully, and keep it in a safe place for later reference.
- This instruction manual contains information for models AR2000S(A), AR2000M(A) and AR2000H(A). Be sure to refer to information that is applicable to the model you are using.
- This is Original instructions. (Original Instruction Manual is written in English language.)

MANUFACTURER
LOBTEX CO.,LTD.
 International Marketing&Sales Division

12-8 Shijo-cho, Higashi-Osaka City
 Osaka 579-8053, Japan

Telephone: +81(72)981-7466 Telefac: +81(72)981-9420
 URL <https://www.lobtex.co.jp/>

INTRODUCTION

Thank you very much for purchasing “LOBSTER” air riveter.

- These are the blind rivet tools which are only used for fixing blind rivets. These tools are not designed for other purposes.
- This instruction manual shows how to use the tools safely, work properly, maintenance and inspection which will make tools more effectively.
- Please check the blind rivets specification and durability on customers side before using it.

1 IMPORTANT NOTICES

- Read this manual carefully before using this tool. Follow instructions in this manual for handling this tool, replacing accessories or replacing parts as needed.
- If you have any questions about this manual, contact the “LOBSTER” dealer where you purchased the tool.
- It is impossible to foresee all potential dangers and describe them in this manual. You must operate this tool paying attention to safety as well as observing the instructions in this manual.
- This manual is translated from Japanese, its original language. It is your own responsibility to achieve a full understanding of the contents of this manual before using the equipment described.
- Lobtex Co., Ltd. has the copyright of this manual. It is prohibited to publish, copy or translate to other language without prior consent.

2 DISCLAIMER

- Our warranty does not apply to direct and indirect damages and lost income caused by the misuse, abuse, and unauthorized modification of the tool. We do not guarantee the strength or quality of blind rivet.
- We do not guarantee any damages and failures caused by any modifications without our written approval.
- We do not guarantee any damages and failures caused by use of parts other than our recommendation.

IMPORTANT SAFETY INSTRUCTIONS



- ◆ Be sure to read the following Important Safety Instructions carefully and make sure that you understand them thoroughly before using this tool.



- ◆ Always wear protective goggles while using the tool.
The blind rivets may jump out by accident and cause injuries.



- ◆ This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
- ◆ These Important Safety Instructions are divided into **⚠ WARNING** and **⚠ CAUTION**. The differences between these two levels are described below.

⚠ WARNING : Indicates a potentially hazardous situation which, if ignored, may result in death or serious injury to the operator.

⚠ CAUTION : Indicates a potentially hazardous situation which, if ignored, may result in moderate injury to the operator or physical damage.

Moreover, failure to follow the instructions marked with the **⚠ CAUTION** symbol or cautions without a

⚠ CAUTION symbol which appear in the text of this manual may also have serious results in some cases. Always be sure to observe the instructions given in the Important Safety Instructions.

- ◆ After reading this manual, keep it in a safe place where it is easily accessible to all users.



WARNING

1. The air pressure should be kept within the range of 0.5 to 0.6 MPa (71 to 85 psi).

- If an air pressure which is greater than this is used, the tool may become damaged, and injury or damage to property may result.

2. Always attach the Safety Cap before use.

- If this is not observed, the mandrel may eject out when the blind rivets are cut and cause serious injury.

3. Be sure to remove the Frame Head when adding hydraulic oil through the Cylinder.

- If the Frame Head is not removed before adding oil, excess oil may remain inside the tool, and damage to the tool or personal injury may result. (Except the case when adding hydraulic oil through the Bleed Plug.)

4. Make sure that the tool and the air source are connected securely.

- If the threads of the Rotary Joint Unit do not match or if the screws are not inserted far enough, the air hose may become disconnected during use and injury may result.
- Use hose bands to securely connect the air hose joint and air hose. If they are not securely connected, the air hose may become disconnected during use and injury may result.

5. Turn off the air supply before disconnecting the tool from the air source.

- Compressed air may cause the air hose to whip around and injury may result.

6. Check that all the tool parts are free from damage before use. Any damaged parts should be repaired before the tool is used.

- If the tool is used while any parts are damaged, injury may result.
- If the tool is damaged by objects being dropped onto it, the damaged part may break and accident or injury may result.
- Don't pull and drag the tool by the air hose. It may trigger some damages on the tool body, breakage of rotary joint unit or some other defects and lead serious troubles with injuries.

7. If using in elevated locations, use a safety harness, and take care to avoid dropping blind rivets or the tool itself.

- Accident or injury may result if this practice is not followed.

8. Never look into the Nosepiece of the tool, and never point the nosepiece toward other persons.

- If the tool is used while the cut mandrels are still inside the tool not being ejected these mandrels may be ejected from the tool's nosepiece during use and cause serious injury.

9. Wear protective glasses during use.

- Failure to do so may result in an accident or personal injury in case that a blind rivet or a piece of cut mandrels jumps out toward you.



CAUTION


1. **Before starting maintenance or disassembling the unit to replace parts, be sure to stop air supply.**
 - Performing maintenance or disassembly with air supplied may cause a part to jump out, oil to squirt out, or the unit to perform unexpected behavior, and may result in an accident or personal injury.
2. **Do not operate the tool without equipped the Frame Head.**
 - Items such as fingers or a hand may become caught in the mechanism.
3. **Do not bring your face close to the Air Outlet holes.**
 - Pressurized air containing fine particles is discharged from the Air Outlet Holes during use. Keep eyes away from this area.
4. **Avoid skin contact with substances such as hydraulic oil, lubricating oil and grease.**
 - Such substances may cause inflammation of the skin. If they come into contact with your skin, wash the affected area thoroughly.
5. **Make sure that the workplace is safe, clean and organized.**
 - Accidents can easily occur in untidy workplaces.
 - If the cut mandrels are allowed to fall onto the floor, you may slip on them, and injury may result.
6. **Avoid uncomfortable postures while working.**
 - You may fall down and injury may result.
7. **Keep people who are not involved in work away from the workplace.**
 - Accidents or injury may result.
8. **Maintain the tool with due care.**
 - Refer to the Instruction Manual for details on replacing parts and attachments, otherwise injury may occur.
 - Keep the hand grip dry and clean, and avoid adhesion of oil and grease. Otherwise the grip may slip from your hand resulting in falling of the unit.
9. **Ask Lobtex to carry out any repair work required.**
 - Repair work should only be carried out by a qualified technician. Please contact your nearest "LOBSTER" distributor, representative, or direct to Lobtex Co., Ltd., Osaka. If the tool is repaired by someone without the necessary qualifications and experience, the tool may not perform to optimum standards, and accidents or injury may result.
10. **Do not attempt to modify the tool.**
 - Unauthorized modifications may cause malfunctions which can lead to accidents or injury.
11. **Only for EU countries, do not dispose of electric tools together with household waste material !**
 - In observance of European Directive 2002/96/EC on waste electrical and electronic equipment and its implementation in accordance with national law, electric tools that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility.
12. **The parts to be used must be those supplied from Lobtex or recommended by Lobtex. Select and attach parts applicable to your blind rivet.**
 - Otherwise the unit may not produce maximum performance and may malfunction resulting in an accident or personal injury.
13. **Do not leave the floor littered with cut-mandrels.**
 - Cut-mandrels are dangerous because their ends are sharp. Stepping on them is also dangerous easily causing a slip and fall accident.
14. **The production date of this product is shown brevity code on the cylinder top. (on page 6)**



CAUTION


15. The Warning Label includes important information and tips on using the tool. If the label becomes so dirty or damaged that it cannot be read, order and replace it with a new label. You can order a new label from Lobtex Co., Ltd. through our dealers.
16. This product is a tool for exclusive use of the professional business. When you are the one who uses this tool for the first time, please receive an instruction from the one who has already used this tool before, also please read the Instruction Manual carefully and understand the content.
 - Wear protective goggles or safety glasses.
 - If the tool is broken, do not operate.
17. For the maintenance of the main body, for every 30,000 installation of the fastener or in one year.
18. Only persons who are well trained and qualified should use, adjust, and maintain this product.
19. Do not modify the tool. Any modification to the equipment impairs the validity of safety devices, leading to a higher risk to operators.
20. Be aware of slippery surfaces caused by use of the tool and also of trip hazards caused by the air line or hydraulic hose.
21. Proceed with care in unfamiliar surroundings. There can be hidden hazards, such as electrical or other utility cables.
22. This tool is not intended for use in potentially explosive atmospheres and is not insulated against contact with electric power.
23. Ensure that there are no electrical cables, gas pipes, etc., which can cause a hazard if damaged by use of the tool.
24. If you experience numbness, tingling, pain or whitening of the skin in your fingers or hands, stop using the tool, inform your employer and consult a physician.
25. Compressed air can cause severe injury:
 - Be sure to disconnect the tool from the air supply source when it is not in use or before replacing or repairing it.
 - Never direct air at yourself or anyone else.
26. Whipping hoses can cause severe injury. Always make sure there are no damages on hoses and no loose fittings.
27. Do not carry the pneumatic tool by holding the hose.
28. Preventative maintenance should be carried out, after a specified time of operation, a specified number of cycles/operations or a stated number of times per year.
29. When you handle oil or grease, obtain the material safety data sheet (SDS) from the supplier, and follow the described instructions.
30. Tighten the Bleed Plug firmly before use.
 - If the bleed plug is loose or coming off during use, oil may squirt out resulting in an accident or personal injury.
31. Using the tool repeatedly may cause pain in your hands, shoulders, neck, and other locations.
 - To avoid pain and fatigue, assume an appropriate and natural posture, and change your posture as necessary.
 - If you suffer from continuous discomfort, pain, numbness, palpitations, stiffness, or hot flashes, do not ignore it. Consult with your employer and health manager.

NOMENCLATURE




FRAME HEAD INTERNAL PARTS


AR2000S(A)



AR2000M(A)



AR2000H(A)



TECHNICAL DATA

Model No.		AR2000S (A)	AR2000M (A)	AR2000H (A)
Weight	kg (lbs)	1.1 (2.43)	1.2 (2.65)	1.6 (3.53)
Operating air pressure		0.5 ~ 0.6 MPa (71 ~ 85 psi.)		
Dimensions (Length×Height×Width)	mm	266×240×95	270×283×95	295×323×105
Air consumption per blind rivet	ℓ (c.ft.)	0.6 (0.021)	1.7 (0.060)	3.6 (0.127)
Tool stroke	mm (inch)	14 (35/64)	16 (5/8)	18.5 (23/32)
Traction power at 0.6 MPa	(kN)	4.8	9.1	14.0
Applicable blind rivets (rivet diameters)	Φ mm Φ inch	2.4, 3.2, 4.0 *	2.4, 3.2, 4.0, 4.8 3/32, 1/8, 5/32, 3/16	4.8, 6.4 3/16, 1/4
Operating environment	Temperature	4 °C to 35 °C		
	Relative humidity	80%RH max. (no condensation)		
Sound	Pressure level (Lpa)	75 dB		
Vibration	Emission value	Less than or equal to 2.5 m/sec ²		
Air intake (Rotary joint)		Size of screw G1/4 (PF1/4)		


* 4.0 mm stainless rivets can not be used.

- Product specifications and design are subject to change for improvement without notice.
- Weight and dimensions given are standard values.

Actual products may differ slightly from the values given.

- AR2000H(A) is available to install 2.4 (3/32"), 3.2 (1/8") and 4.0 (5/32") blind rivets subject to conversion of jaw case head, ultra jaws, pusher and nosepiece.

Index no.	Part name	Code no.
3	Jaw case head 'M'	14378
4	Ultra Jaws (pair) 'M'	10281
6	Jaw pusher 'H'	10224
1	Nosepiece 'L' 2.4	10213
1	Nosepiece 'L' 3.2	10214
1	Nosepiece 'L' 4.0	10215



Manufacturing year of unit	➡ Indicated on the Cylinder top unit
Warning label	➡ Attached on the side of Air Cylinder

* Rated plate and caution plate is identical.

How to read the year and month of production

A year/month of manufacture	1	2	3	4	5	6	7	8	9	10	11	12
An English character	A	B	M	N	K	W	T	Y	U	O	L	Z

Example

year: 20②③ month: ③

Serial No. : BMM O O O O

■ Air consumption calculation method ■

Use the following calculation method to obtain the required air consumption, and select the compressor accordingly.

Required air consumption = Air consumption per blind rivet × No. of blind rivets per minute


Make sure that this corresponds to the compressor discharge capacity (per minute).

PREPARATION BEFORE USE

- 1 Remove the dust-proof cap on the bottom of the tool, and then connect the rotary joint unit.


☑ Connect the end of the rotary joint unit which has the O-ring fitted to the tool.

⚠ WARNING4 (P.2)



- 2 Install the safety cap to the tool.


⚠ WARNING2 (P.2)



- 3 Set up the compressor and be sure to install an air filter, air regulator and air lubricator (3-device set) between the compressor and the tool.

ATTENTION:

In case of the usage in the cold district, the moisture laden air in the tool body may be freeze on the inside cylinder surface. As the result, it may not work. To dehydrate, we recommend to add the air-dryer unit to the normal three units (Regulator, Filter, and Lubricator).



- 4 Use the air regulator to adjust the operating air pressure to 0.5 ~ 0.6 MPa (71 ~ 85 psi). **⚠ WARNING1 (P.2)**

☑ If installing stainless steel rivets with a diameter of 4.8 mm (3/16") with the AR2000M(A), set the air pressure to 0.55 ~ 0.6 MPa (78 ~ 85 psi).


ATTENTION:

If the air pressure is too high, damage to parts may occur. If the pressure is too low, some size of the blind rivet may not be correctly installed (cut).

- 5 Replace the nosepiece to conform to the size of the blind rivet being used.

The blind rivet size indicates the diameter of the blind rivet.

Rivet diameter



NOTE:

- Different-sized rivets can be used just by replacing the nosepiece.
- At the time of purchase, the AR2000S(A) and AR2000M(A) are fitted with a 3.2 nosepiece, and the AR2000H(A) is fitted with a 4.8 nosepiece.
- If you wish to use other sizes, use a spanner to remove and replace the nosepiece.

⚠ CAUTION Nosepiece Selection

Conform the size to be used, and replace the nosepiece with the corresponding one. Wrong size selection of the nosepiece will cause jamming the spent mandrel inside.

OPERATING THE AIR RIVETER

1 Select a blind rivet of a size which is suitable for the workpiece to be riveted.

2 Replace the nosepiece with one which matches the size of the blind rivet to be used. (Refer to item **5** in “Preparation Before Use” on page 7.)

3 Drill a hole of appropriate size (0.1 to 0.2 mm larger than the diameter of the blind rivet) into the workpiece.



4 Insert the blind rivet into the hole.

ATTENTION:

Some blind rivets have mandrels with sharp ends.
Be careful not to injure your fingers.



5 Place the nosepiece of the air riveter over the mandrel of the blind rivet.



6 Gently press the nosepiece of the air riveter against the workpiece. After checking that there is no gap between the nosepiece and workpiece, press the switch.

❑ When you pull the switch or during the keeping pull position, you may find a little air leak from the point of this switch. This is not the defective of the quality but the normal condition.



7 The blind rivet will be installed into the workpiece.



8 Release the switch, and then tilt the air riveter to remove the cut mandrel from the nosepiece or safety cap.

NOTE: Make sure that the cut mandrel has been completely removed before proceeding to the next riveting.

< Operating temperature >

The ambient temperature for working is within the range of 4 ~ 35°C (39.2 ~ 95°F).

MAINTENANCE

After long periods of use, debris from rivet mandrel and other foreign materials tend to build up in various parts of the tool and the hydraulic oil level may drop, both of which can lead to operating problems. The tool should be cleaned periodically.

⚠ WARNING In case you have some trouble and failure, please refer "Troubleshooting" in the Instruction Manual.

1 Jaw maintenance **Also refer to this section when replacing parts.**

- ◎ With debris builds up, the jaws will not move smoothly and normal operation will not be possible.
- ◎ The jaws should be cleaned on average once every 3,000 riveting operations.
- The 3,000 riveting is a rough standard. This may change depending on usage environment.

1 Turn off the air supply. **⚠ CAUTION1 (P.3)**






2 Use spanner or similar tool to remove the frame head. **⚠ CAUTION2 (P.3)**

3 **AR2000S(A)**

Use a spanner or similar tool to loosen and remove the jaw case, and then remove the jaw pusher spring, jaw pusher and jaws.

AR2000M(A) / AR2000H(A)

Pull backwards the jaw case collar to loosen and remove the jaw case head, and then remove the jaw pusher spring, jaw pusher, O-ring and jaws.



4 Use a brush or similar to clean all parts.



5 AR2000S(A)

Reassemble by following the disassembly procedure in reverse. Install the jaw case so that its distance matches those shown in the illustration at right.

AR2000M(A) / AR2000H(A)

Reassemble by following the disassembly procedure in reverse. Tighten the jaw case head fully, and then turn it back so that the notch is aligned with the tab on the jaw case collar, and move the collar into place.



- ❑ Apply the accompanying Jaw Lube or optional Lobster Jaw Lube JO50. The lubricant oil should be applied on average once every 1,000 riveting operations.

NOTE:

- When re-assembling, be sure to apply a lubricant such as grease to all moving and sliding parts.
- Be careful not to leave out any parts, and tighten all connections securely.
- The jaws are consumable parts, and they should be replaced periodically.
- In the case of the AR2000M(A) and AR2000H(A), the jaw case and jaw case lock nut do not need to be removed during maintenance. If they are removed by mistake, replace them so that the distance matches those shown in the illustration at right.

< Jaw case setting position >

AR2000S(A)



Lower the Jaw Case Collar and align the notched section


< Jaw Case Head (Cross section) >

Apply jaw lube (lubricating oil)




< Jaw case setting position >

AR2000M(A)



AR2000H(A)



2 Cleaning and filling the cylinder

© If foreign materials build up in the cylinder, it will not operate smoothly and service life will be reduced.

DISASSEMBLY

1 Turn off the air supply. ⚠ CAUTION1 (P.3)

2 Use a spanner or similar tool to remove the frame head.

⚠ WARNING 3 (P.2)

Be sure to remove the frame head when adding hydraulic oil through the cylinder.


3 Use a Phillips screwdriver to remove the four tapping screws on the cylinder top, and then separate the cylinder and the frame.

❑ Hold the frame vertical, as the hydraulic oil will spill out if it is tipped sideways.

4 Hold the frame upside down and pull the air piston out from the cylinder top.

❑ Air Piston may remain inside Cylinder cup.

5 Remove the cylinder cup from the cylinder cover.




Frame head



Tapping screw

Cylinder top



Air piston

Cylinder cup

Cylinder cover

Muffler


Cylinder top

CLEANING

6 Use a rag, brush or similar to clean all parts.

FILLING OIL

7 Fill with hydraulic oil until just before the oil starts running out from the filling hole.



Cylinder top

Oil filling hole


RE-ASSEMBLY

8 Apply grease to the inside of the cylinder cup and to the O-ring and rod of the piston.



Apply grease

Cylinder cup



Apply grease

Air piston

Apply grease

9 Put the cylinder cup back in the cylinder cover.


10 Put the air piston back inside the cylinder cup.

❑ AT that time, the air piston is susceptible to falling inside the cylinder cup. Carefully press the air piston straight to the bottom. (10-1)

If the piston is not seated straight, remove it and then press it again. Do not forcibly press the inclining piston. (10-2)



11 Put the air cylinder containing the air piston together with the cylinder top. Hold them down while fastening the four tapping screws.



12 After all parts have been reassembled but before the frame head has been re-attached, hold the tool so that the bleed plug (hexagon socket head cap screw) is facing directly upward, and use the accessory hex key wrench to loosen the bleed plug to drain any excess oil. After checking that no more oil is coming out, re-tighten the bleed plug.

❑ Be careful when loosening the bleed plug, as the hydraulic oil may spill out rapidly.



13 Wipe away any oil around the tool and clean up any spilled oil before using the tool.

⚠ CAUTION4 (P.3) ⚠ CAUTION8 (P.3)

14 After checking the jaw case setting position, install the frame head. (Refer to pages 10.)

NOTE:

- Be careful not to allow any debris or other foreign materials get into the hydraulic oil or the cylinder during disassembly and re-assembly.
- The hydraulic oil should be changed on average once every 30,000 riveting operation.


3 Cleaning the spool

DISASSEMBLY

1 Turn off the air supply.  **CAUTION1 (P.3)**


2 Use a spanner or similar tool to remove the change plugs at the front and back.

3 Use a plastic screwdriver or similar to push out the spool from the rear hole.



CLEANING

4 Use a brush or similar to clean all parts. Check the spool thoroughly to ensure that none of the small holes in the spool are blocked.



RE-ASSEMBLY

5 Reassemble by following the disassembly procedure in reverse.

- ❑ Apply grease to the O-ring of the spool before reassembly.
- ❑ The front and rear change plugs and the change plug of the air hose connector (refer to page 5) have the same shape, so be careful not to confuse them.

4 Adding oil


© Oil addition should always be carried out by following the procedure given below.

DISASSEMBLY

1 Turn off the air supply.  **CAUTION1 (P.3)**

2 Use the accessory hex key wrench to remove the bleed plug and seal washer, and attach the priming pump (syringe unit) to the hole.

- ❑ Make sure that the priming pump contains the necessary amount of oil beforehand.
- ❑ If you hold the main body of the priming pump while tightening, the pump may become damaged. Use pliers to hold the nozzle of priming pump while tightening.



FILLING OIL

3 Gently depress the piston of the priming pump.

- ❑ When enough hydraulic oil has been added, the piston will become hard to push. Stop adding oil at this point.

RE-ASSEMBLY

4 Install the bleed plug and seal washer.

STORAGE

- Store in a place which is well-ventilated and free from excessive dust and humidity, and where there is no danger that tool will fall.
- If the tool will not be used for a long period of time, inspect the parts as shown in "Maintenance" on pages 9 to 14 prior to storing the tool.
- To increase the working life of the tool, it is recommended that you perform the periodic overhauls. Contact the place of purchase or your nearest "LOBSTER" dealer for any overhauls and repair work required.
(A charge will be made for this service.)

TROUBLESHOOTING

If a problem occurs, check the following.

If the problem persists after checking the items in the table below, contact your nearest "LOBSTER" dealer or direct to us.

In making any inquiries about this product or requests for repair work, first check the troubleshooting below and then make a note of the model number, the usage conditions and the trouble symptoms in as much detail as possible. If you can provide this kind of information, it will help in reducing the amount of time required for delivery or repairs to be completed.

Trouble	Cause	Countermeasure
The blind rivet does not go in or the mandrel does not come out after riveting.	1 Incorrect combination of replacement parts being used.	Replace with the correct part which matches the blind rivet size. (Refer to page 7.)
	2 Nosepiece or frame head is loose.	Use a spanner or similar to tighten securely.
	3 Jaw case is incorrectly assembled.	Check the jaw case setting position. (Refer to pages 9.)
	4 Contact surfaces between the jaws and the jaw case head are not smooth.	Clean the jaws and inside the jaw case head, and apply "LOBSTER" brand jaw lube (or spray-type lubricating oil or the accessory hydraulic oil) to the backs of the jaws. (Refer to page 9 and 10.)
	5 The inside of the cylinder is dirty so that the air piston cannot return to its proper position.	Clean inside the cylinder, and apply grease inside the cylinder and to the o-ring. (Refer to pages 11 and 12.)
	6 Oil filling was not performed correctly, so that there is excess hydraulic oil inside the tool.	Loosen the bleed plug to allow the excess hydraulic oil to drain out. (Refer to page 12.)
Number of switch operations increases before riveting is complete.	1 The blind rivet length is not correct for the workpiece thickness.	Use blind rivets which match the workpiece thickness.
	2 Compressor air pressure is incorrect.	Check the air pressure.
	3 Jaw case is incorrectly assembled.	Check the jaw case setting position. (Refer to pages 9.)
	4 Jaws are worn.	Replace the jaws. (Refer to page 9 and 10.)
	5 Insufficient hydraulic oil, causing a shorter stroke.	Add hydraulic oil. (Refer to page 14.)
Piston does not operate or returns very slowly or operation is not smooth.	1 Spool is not moving properly.	I Remove the rear part of change-plug (Refer to page 13) and push the spool 2 ~ 3 mm with a plastic (soft) stick. In case of no improvement, take the II measure.
		II Clean the spool and apply grease to the o-rings. (Refer to page 13.)
	2 Air outlet hole muffler is blocked.	Replace the muffler. (Refer to pages 11 and 12.)
	3 The inside of the cylinder is dirty so that the air piston cannot return to its proper position.	Clean inside the cylinder, and apply grease inside the cylinder and to the o-ring. (Refer to pages 11 and 12.)

ULTRA JAWS (AR2000M (A) / AR2000H (A))

The AR2000M(A) and AR2000H(A) use ultra jaws which have greater durability. Be sure to specify "Ultra jaws M" (AR2000M(A)) or "Ultra jaws H" (AR2000H(A)) as replacement parts for these models.

HYDRULIC OIL REQUIREMENTS

Use only clean hydraulic oil, as the viscosity of the oil used will affect tool performance.

"LOBSTER" brand Hydraulic Oil is supplied in a plastic filler bottle with the tool, and can also be obtained from your "Lobster" dealer or agent in your town. If this is not possible, a good quality mineral oil with the following properties should also be used.

Viscosity ISO	: VG46	RECOMMENDED OILS are:
Viscosity Index	: 113	
Viscosity at 40°C	: 46 c.s.t.	
Viscosity at 100°C	: 7.06 c.s.t.	
Flash Point	: 228	
		Shell Tellus No. 46
		Esso Teresso No. 46
		Mobil D.T.E. 25 Oil (Medium)

MEMO

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....


.....

.....

.....

.....

.....



AR2000S (A) PARTS TABLE

Index No.	Part name	Code No.	Material	Index No.	Part name	Code No.	Material
1-A	Nosepiece 'S' 2.4 (3/32)	10027	Steel	32	Pan head tapping screw 3×10	29340	Steel
1-B	Nosepiece 'S' 3.2 (1/8)	10028	Steel	33	Flat head tapping screw 5×35	29367	Steel
1-C	Nosepiece 'S' 4.0 (5/32)	10029	Steel	34* ²	Cylinder top unit	44562	④
2	Frame head 'S'	29801	Steel	35	Muffler	29377	Plastic
③	Jaw case	10173	Steel	36	Frame lock nut	29757	Steel
④	Jaws (pair) 'S'	10032	Steel	37	Rubber cushion 'H'	29736	Rubber
⑤	Jaw pusher	10132	Steel	38* ³	Air piston unit 'S'	44704	⑤
⑥	Jaw pusher spring	10133	Steel	39	O-ring P-60	10134	Rubber
7	Lock washer	10148	Steel	40	Cylinder cup 'S'	29824	Aluminum
8	Jaw case lock nut	10113	Steel	41	Grommet	29361	Rubber
9* ¹	Frame unit 'SA'	44561	①	42	Warning label	61075	Plastic
10	Bleed plug (Hexagon socket head cap screw)	29337	Steel	43	O-ring S-5	10276	Rubber
11	Sealing washer	63209	Rubber	44	Cylinder cover 'S'	29822	Plastic
12	Polyurethane tube 220 mm	44706	Plastic	45	Exhaust plate	42838	Steel
13	Connector	29354	②	46	O-ring P-10	10274	Rubber
14	O-ring P-12	10128	Rubber	47	O-ring P-6	10150	Rubber
15	B-ring P-12	10129	Plastic	48	Change plug	29375	Plastic
16	Oil piston 'X'	41258	Steel	49	O-ring P-9	10219	Rubber
17	O-ring P-18	23683	Rubber	50	Pan head tapping screw 4×20	29610	Steel
18	B-ring P-18	23684	Plastic	51	Cylinder bottom	29366	Aluminum
19	Back piston 'X'	41261	Aluminum	52	Spool	29612	Brass
20	O-ring P-7	10149	Rubber	53	O-ring P-5 (4D)	29613	Rubber
21	Return spring 'S'	29815	Steel	54	O-ring P-8 (4D)	29614	Rubber
22	O-ring S-24	10185	Rubber	55	Rotary joint	42501	Aluminum
23	Hanger clip 'S'	29819	Steel	56	Retaining ring E-7	10285	Steel
24	Frame cap 'S'	29817	Aluminum	57	Nipple	42479	Aluminum
25	Safety cap	42505	Rubber	58	O-ring S-10	10151	Rubber
26	Switch	29348	Plastic	59	Rotary joint unit	42502	①
27	Valve sleeve	29350	⑥	60	"LOBSTER" brand hydraulic oil	10012	----
28	Miniature Connector	42510	③	61	Spanner 'B'	29642	Steel
29	Polyurethane tube 115 mm	44705	Plastic	62	Spanner 'A'	10183	Steel
30	Frame cover 'MA-R'	42478	Plastic	63	Hex key wrench 5 mm	25777	Steel
31	Frame cover 'MA-L'	42500	Plastic	64	Priming pump (syringe unit)	29624	②
				65* ⁴	"LOBSTER" lubricant oil JO-50	—	----

* ¹ Part no. 9 includes part nos. 10, 11, 14, and 15.

* ² Part no. 34 includes part nos. 12, 27, 28, 29, and 35.

* ³ Part no. 38 includes part nos. 37, and 39.

* ⁴ When No.65 is depleted, please order the separately sold JO50 (Code No.889).

Parts with circled Index No. are consumable parts. They should be replaced periodically.

① Aluminum, Rubber, Steel, Plastic

② Brass, Rubber, Plastic

③ Brass, Rubber

④ Aluminum, Brass, Rubber, Stainless, Plastic

⑤ Aluminum, Rubber, Steel

⑥ Brass, Rubber, Stainless


ORDERING PARTS


Indicate the tool model, part name, code no. and quantity as shown below when ordering.

Model	Part name	Code No.	Qty.
AR2000S(A)	Jaws (pair) 'S'	10032	1
AR2000S(A)	Frame head 'S'	29801	1

* When parts are modified for improvement, the older parts are kept in stock for a period of five years.

AR2000M (A) EXPLODED VIEW





AR2000M(A) PARTS TABLE

Index No.	Part name	Code No.	Material	Index No.	Part name	Code No.	Material
1-A	Nosepiece 'S' 2.4 (3/32)	10027	Steel	33	Frame cover 'MA-L'	42500	Plastic
1-B	Nosepiece 'S' 3.2 (1/8)	10028	Steel	34	Pan head tapping screw 3×10	29340	Steel
1-C	Nosepiece 'S' 4.0 (5/32)	10029	Steel	35	Flat head tapping screw 5×35	29367	Steel
1-D	Nosepiece 'S' 4.0 (5/32)	10030	Steel	36* ²	Cylinder top unit	42492	④
2	Frame head 'M'	29332	Steel	37	Muffler	29377	Plastic
③	Jaw case head	10280	Steel	38	Frame lock nut	29757	Steel
④	Ultra Jaws (pair) 'M'	10281	Steel	39	Rubber cushion 'H'	29736	Rubber
⑤	Jaw case	10279	Steel	40* ³	Air piston unit 'M'	29635	⑤
⑥	O-ring P-10	10274	Rubber	41	O-ring P-60	10134	Rubber
⑦	Jaw pusher	10132	Steel	42	Cylinder cup 'M'	29360	Aluminum
⑧	Jaw pusher spring	10133	Steel	43	Grommet	29361	Rubber
9	Jaw case collar	10286	Steel	44	Warning label	61075	Plastic
10	Collar spring	10287	Steel	45	O-ring S-5	10276	Rubber
11	Lock washer	10148	Steel	46	Cylinder cover 'M'	29359	Plastic
12	Jaw case lock nut	10113	Steel	47	Rubber plate MA	42836	Rubber
13* ¹	Frame unit 'MA'	42486	①	48	O-ring P-6	10150	Rubber
14	Bleed plug (Hexagon socket head cap screw)	29337	Steel	49	Change plug	29375	Plastic
				50	O-ring P-9	10219	Rubber
15	Sealing washer	63209	Rubber	51	Pan head tapping screw 4×20	29610	Steel
16	O-ring P-12	10128	Rubber	52	Cylinder bottom	29366	Aluminum
17	B-ring P-12	10129	Plastic	53	Spool	29612	Brass
18	Oil piston 'Y'	41264	Steel	54	O-ring P-5 (4D)	29613	Rubber
19	O-ring P-22A	10130	Rubber	55	O-ring P-8 (4D)	29614	Rubber
20	B-ring P-22A	10131	Plastic	56	Rotary joint	42501	Aluminum
21	Piston sleeve	42498	Aluminum	57	Retaining ring E-7	10285	Steel
22	Flat washer 12×24	42504	Steel	58	O-ring P-7	10149	Rubber
23	Return spring 'M'	29345	Steel	59	Nipple	42479	Aluminum
24	O-ring S-30	23685	Rubber	60	O-ring S-10	10151	Rubber
25	Hanger clip	10106	Steel	61	Rotary joint unit	42502	①
26	Frame cap 'M'	42487	Aluminum	62	"LOBSTER" brand hydraulic oil	10012	----
27	Safety cap	42505	Rubber	63	Spanner 'B'	29642	Steel
28	Switch	29348	Plastic	64	Spanner 'A'	10141	Steel
29	Valve sleeve	29350	⑥	65	Hex key wrench 5 mm	25777	Steel
30	Miniature Connector	42510	③	66	Priming pump (syringe unit)	29624	②
31	Polyurethane tube 115 mm	44705	Plastic	67* ⁴	"LOBSTER" lubricant oil JO-50	—	----
32	Frame cover 'MA-R'	42478	Plastic				

* ¹ Part no. 13 includes part nos. 14, 15, 16, and 17.

* ² Part no. 36 includes part nos. 29, 30, 31, and 37.

* ³ Part no. 40 includes part nos. 39, and 41.

* ⁴ When No.67 is depleted, please order the separately sold JO50 (Code No.889).

Parts with circled Index No. are consumable parts. They should be replaced periodically.

① Aluminum, Rubber, Steel, Plastic

② Brass, Rubber, Plastic

③ Brass, Rubber

④ Aluminum, Brass, Rubber, Stainless, Plastic

⑤ Aluminum, Rubber, Steel

⑥ Brass, Rubber, Stainless

ORDERING PARTS

Indicate the tool model, part name, code no. and quantity as shown below when ordering.

Model	Part name	Code No.	Qty.
AR2000M(A)	Ultra Jaws (pair) 'M'	10281	1
AR2000M(A)	Frame head 'M'	29332	1

* When parts are modified for improvement, the older parts are kept in stock for a period of five years.



AR2000H(A) PARTS TABLE

Index No.	Part name	Code No.	Material	Index No.	Part name	Code No.	Material
1-A	Nosepiece 'L' 4.8 (3/16)	10216	Steel	34	Frame cover 'HA-R'	44551	Plastic
1-B	Nosepiece 'H' 6.4 (1/4)	10226	Steel	35	Frame cover 'HA-L'	44552	Plastic
2	Frame head 'H'	29709	Steel	36	Pan head tapping screw 3×10	29340	Steel
③	Jaw case head 'H'	10447	Steel	37	Flat head tapping screw 5×35	29367	Steel
④	Ultra Jaws (pair) 'H'	10493	Steel	38* ²	Cylinder top unit	43586	④
⑤	Jaw case	10429	Steel	39	Muffler 'HA'	44567	Plastic
⑥	Jaw pusher 'H'	29710	Steel	40	Frame lock nut 'H'	29757	Steel
⑦	Jaw pusher spring 'H'	29711	Steel	41	Rubber cushion 'H'	29736	Rubber
8	Jaw case collar	10448	Steel	40* ³	Air piston unit 'H'	29758	⑤
9	Collar spring	10449	Steel	43	O-ring P-70	10212	Rubber
10	Lock washer	10148	Steel	44	Cylinder cup 'H'	29741	Aluminum
11	Jaw case lock nut 'H'	29712	Steel	45	Grommet	29361	Rubber
12	Stop ring	23634	Steel	46	O-ring S-5	10276	Rubber
13* ¹	Frame unit 'HA'	44703	①	47	Warning label	61075	Plastic
14	Bleed plug (Hexagon socket head cap screw)	29337	Steel	48	Cylinder cover 'H'	29740	Plastic
				49	O-ring P-10	10274	Rubber
15	Sealing washer	63209	Rubber	50	O-ring P-7	10149	Rubber
16	Polyurethane tube 230 mm	29730	Plastic	51	Change plug	29375	Plastic
17	Connector	29354	②	52	O-ring P-9	10219	Rubber
18	O-ring P-12	10128	Rubber	53	Pan head tapping screw 4×20	29610	Steel
19	B-ring P-12	10129	Plastic	54	Cylinder bottom 'H'	29739	Aluminum
20	Oil piston 'Z'	41270	Steel	55	Spool	29612	Brass
21	O-ring P-24	10207	Rubber	56	O-ring P-5 (4D)	29613	Rubber
22	B-ring P-24	10208	Plastic	57	O-ring P-8 (4D)	29614	Rubber
23	Back piston 'Z'	41273	Aluminum	58	Rotary joint	42501	Aluminum
24	O-ring P-8	10336	Rubber	59	Retaining ring E-7	10285	Steel
25	Return spring 'H'	29726	Steel	60	Nipple	42479	Aluminum
26	O-ring S-32	29727	Rubber	61	O-ring S-10	10151	Rubber
27	Hanger clip	10192	Steel	62	Rotary joint unit	42502	①
28	Frame cap 'H'	29728	Aluminum	63	"LOBSTER" brand hydraulic oil	10012	----
29	Safety cap	42505	Rubber	64	Spanner 'B'	29642	Steel
30	Switch	29348	Plastic	65	Spanner 'A'	10217	Steel
31	Valve sleeve	29350	⑥	66	Hex key wrench 5 mm	25777	Steel
32	Miniature Connector	42510	③	67	Priming pump (syringe unit)	29624	②
33	Polyurethane tube 125 mm	29729	Plastic	68* ⁴	"LOBSTER" lubricant oil JO-50	—	----

* ¹ Part no. 13 includes part nos. 12, 14, 15, 18, and 19.

* ² Part no. 38 includes part nos. 16, 31, 32, 33, and 39.

* ³ Part no. 42 includes part nos. 41, and 43.

* ⁴ When No.68 is depleted, please order the separately sold JO50 (Code No.889).

Parts with circled Index No. are consumable parts. They should be replaced periodically.

① Aluminum, Rubber, Steel, Plastic

② Brass, Rubber, Plastic

③ Brass, Rubber

④ Aluminum, Brass, Rubber, Stainless, Plastic

⑤ Aluminum, Rubber, Steel

⑥ Brass, Rubber, Stainless

ORDERING PARTS

Indicate the tool model, part name, code no. and quantity as shown below when ordering.

Model	Part name	Code No.	Qty.
AR2000H(A)	Ultra Jaws (pair) 'H'	10493	1
AR2000H(A)	Frame head 'H'	29709	1

* When parts are modified for improvement, the older parts are kept in stock for a period of five years.

WARRANTY & SERVICE

LOBSTER[®] WARRANTS THAT GOODS COVERED BY THIS MANUAL WILL CONFORM TO APPLICABLE SPECIFICATIONS AND DRAWINGS AND THAT SUCH GOODS WILL BE MANUFACTURED AND INSPECTED ACCORDING TO GENERALLY ACCEPTED PRACTICES OF COMPANIES MANUFACTURING INDUSTRIAL TOOLS. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE FOREGOING.

THE LIABILITY OF LOBSTER[®] ON PARTS FOUND TO BE DEFECTIVE IS LIMITED TO RE-WORK OR THE REPLACEMENT OF SUCH GOODS AND IN NO CASE TO EXCEED THE INVOICE VALUE OF THE SAID GOODS. UNDER NO CIRCUMSTANCES WILL LOBSTER[®] BE LIABLE FOR DAMAGES OR COSTS INCURRED BY THE BUYER OR SUBSEQUENT USER IN REPAIRING OR REPLACING DEFECTIVE GOODS.

ROUTINE MAINTENANCE AND REPAIR OF LOBSTER[®] RIVET TOOLS CAN BE PERFORMED BY AN AVERAGE MECHANIC. HOWEVER, IF YOU HAVE A LOBSTER[®] RIVET TOOL THAT IS IN NEED OF MAJOR REPAIR WE RECOMMEND THAT IT BE SENT DIRECTLY TO US POSTAGE PAID FOR SERVICE AT A REASONABLE CHARGES.

MANUFACTURER

LOBTEX CO., LTD.

OSAKA, JAPAN